

**ANCILLARY COVERAGE**

Rental  
Trip interruption  
Emergency roadside assistance  
Towing  
Jump starts  
Flat tire changes  
Fluid delivery  
Lockout service  
Concierge service

**ENGINE**

Balance shaft  
Cam followers  
Camshaft & camshaft bearings  
Connecting rods and bearings  
Crankshaft and main bearings  
Exhaust manifold  
Hydraulic lifters  
Intake manifold  
Oil pump and oil pump housing  
Pistons  
Piston rings & wrist pins  
Push rods  
Rocker arms  
Shaft  
Bushings & pivots  
Timing chain & guides  
Timing chain tensioner  
Timing gears  
Valve guides  
Lifters & retainers  
Valve seals  
Seats & springs  
Valves (intake and exhaust)  
\*Engine block & cylinder heads  
Valve covers  
Oil pan  
Dipstick & filler tube.

**TURBO/SUPER CHARGER**

Bypass valve  
Clutch & pulley  
Hardlines  
Intercooler  
Nose cone  
Wastegate controller  
All seals & gaskets  
\*Turbocharger/supercharger housing

	STANDARD OPTIONAL COVERAGE			PREMIUM OPTIONAL COVERAGE			EXECUTIVE OPTIONAL COVERAGE			TOP UP OPTIONAL COVERAGE						
	STANDARD	PREMIUM	EXECUTIVE	STANDARD	PREMIUM	EXECUTIVE	STANDARD	PREMIUM	EXECUTIVE	STANDARD	PREMIUM	EXECUTIVE	STANDARD	PREMIUM	EXECUTIVE	TOP UP
<b>TRANSMISSION</b> Bands Bearings Bushings Drums Gears Oil pump Shafts Solenoids Torque converter Vacuum modulator Valve body *Transmission case	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>TRANSFER CASE</b> Gears Shafts Bearings *Transfer case housing	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>DRIVE AXLES</b> Axle bearings Axle shafts Carrier assembly Carrier bearings Hub bearings Output shaft Pinion bearings Ring & pinion Side gears Spider gears *Drive axle housing Differential cover	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>FRONT WHEEL STEERING</b> Center link Idler arm & bushing Main & intermediate column shaft Pitman arm Power steering cooler & lines Power steering hoses Power steering pump Rack & pinion gear Rack & pinion gear housings Reservoir & pulley Steering knuckles/spindles Steering gear box	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>FUEL DELIVERY</b> Fuel pump Fuel injection pump Regulator & injectors	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>BRAKES</b> Compensating valve Disc brake calipers Hydraulic lines & fittings Master cylinder Proportioning valve Vacuum assist booster Wheel cylinders Hydro boost ABS Accumulator ABS Electronic control processor ABS Isolation Dump Valve ABS Pressure Modulator Valve ABS Pump/Motor Assembly ABS Wheel Speed Sensors	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>A/C AIR CONDITIONING</b> Compressor Compressor clutch & pulley Evaporator Belt tensioner Idler pulley & bearing Accumulator/receiver dryer expansion valve Orifice tube	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>ELECTRICAL</b> Alternator Electronic ignition module Headlamp switch Horn assembly Starter motor & solenoid Stop lamp switch Turn signal switch Voltage regulator Windshield wiper motor & switch Washer pumps & switches	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>FUEL DELIVERY</b> Fuel pump Fuel injection pump Regulator & injectors	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>HI-TECH ELECTRICAL</b> Accumulators Automatic load leveling compressor motor Climate control module Convertible top motor & switch Cruise control engagement switch Transducer Servo & amplifier Distributor Electronic control module (ECM) Electronic instrument cluster Electronic trunk release actuator Exciter rings Factory installed rear-view camera Headlamp motors & switch Ignition coils Coil packs & coil pack housing Keyless entry door keypad Mileage computer Oxygen sensor Power antenna motor/mast assembly Power door lock actuator & switch Power mirror motor & switch Power seat motor & switch Power window motor & switch Powertrain control module (PCM) Pump motor/hydraulic motor & relays Rear defogger switch Seat heater switch	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>FRONT SUSPENSION</b> Actuator Ball joints Bearings & bushings Control arms Control arm shafts Control module Height sensor Mode selector switch Solenoid Struts Variable dampening suspension compressor	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>REAR SUSPENSION</b> Bushings and links Mounts & bushings Rear wheel bearings Spindle & spindle support Stabilizer bars Torsion bars	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>HEATING &amp; COOLING</b> Cooling fan clutch & motor Heater core Hot water valve Radiator Radiator fan motor Serpentine belt tensioner Thermostat	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>ULTRA HI-TECH ELECTRICAL</b> Factory installed audio system Factory installed navigation system Back up camera sensors Keyless ignition switch Power door Hatch & trunk motors Power foldings mirrors	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>BODY/ INTERIOR</b> Fuel door Trunk & hood release cables	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>SEALS &amp; GASKETS</b> All seals and gaskets used to contain fluids and lubricants within the Covered Parts of this Plan.	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
<b>DIAGNOSTICS</b> Diagnostic charges up to the first hour	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●

\* If damaged by an internal part



**EXECUTIVE PLUS**

EXCLUSINARY COVERAGE PLAN

**OUR MOST COMPREHENSIVE COVERAGE AVAILABLE**

**THE ONLY COMPONENTS NOT COVERED:**  
Cases, housings, engine block and cylinder heads are covered only if damaged by the failure of an internally lubricated part.

·Non-factory installed electronics including but not limited to DVD players, visual and other electronic equipment (including game systems), telephones, radar detectors, and GPS equipment, audio components including radios, tape players, and compact disc players.

·Graphic equalizers and speakers are not covered regardless of whether they are factory installed.  
·Interior maintenance, adjustment and wear items including but not limited to buttons, carpet, water leaks, dash pad, door and window handles, knobs, rearview mirror (glass and housing), safety belts and restraints and interior trim.

·Batteries, battery cables, belts, brakes (drums, shoes, linings, disc rotors and pads), exhaust emission system, exhaust system (including catalytic converter), charcoal canister, evaporative canister, purge valve, canister vent valve, evaporative lines, evaporative vent control solenoid, flow sensor, vapor separator, lights (bulbs, sealed beam and lenses), headlamps and projection lamp assemblies, fuses, fuse blocks, manual clutch, pressure plate, throw out and pilot bearings, clutch master or slave cylinder, manual transmission clutch disc and lining, strut cartridge inserts, shock absorbers, spark plugs and wires, glow plugs, wheels, wheel studs, wiper arms, wiper blades, friction materials, glass, hoses (except high pressure steering and air conditioning).

·Exterior maintenance, adjustment and wear items including but not limited to the vehicle frame, door panels, exterior trim, glass, body parts, bright metal, bumpers, body panels, door handles, hinges, moldings, outside ornamentation, convertible or vinyl tops, paint, rust, sheet metal, side-view mirrors (glass and housing), water leaks, weather strip, wheel covers/ornaments, bumper, or body parts.

·Replacement of maintenance items (such as spark plugs, timing belt, positive crankcase ventilator valve, filters, lubricants and oil, electrical items) made in connection with normal maintenance services.

·Shop supplies, environmental waste or recycling charges, hazardous waste fees, wheel balancing and tune-ups.

**PARTS NOT COVERED UNLESS REQUIRED IN CONNECTION WITH A BREAKDOWN:**  
Air conditioning recharge, filters, fluids, lubricants, coolants, refrigerants, nuts, bolts and fasteners, toe adjustment and wheel alignments will be covered only if replacement is required in connection with a covered breakdown.

See the contract for specific terms and conditions.

Obligations under this service contract are insured by an insurance policy issued to us by an A+ rated Canadian Insurance Company located at:

Suite 3600, 77 King St. West PO Box 308  
Toronto Ontario M5K 1K2

**INCLUDED WITH ALL COVERAGE PLANS:**

With the purchase of USelect coverage, your satisfaction with your vehicle can continue for years and kilometers to come, knowing that you're protected from many unexpected repairs not covered by the manufacturer's original warranty.

USelect provides coverage for mechanical breakdown repairs beyond the manufacturer's original warranty, so that you can choose the plan that best suits your driving and financial needs.

**ROADSIDE ASSISTANCE:**

- Towing
- Jump starts
- Fluid delivery
- Flat tire changes
- Lockout service
- Concierge service

**SUBSTITUTE TRANSPORTATION**

**TRIP INTERRUPTION**

**CREDIT CARD PAYMENTS**

**NORTH AMERICAN-WIDE SERVICE**

**EMERGENCY ROADSIDE ASSISTANCE**

1-866-209-2856

**CLAIMS ADJUDICATION**

1-866-204-6588

**CLAIMS DEPT. HOURS:**

Monday - Friday 8am - 8pm eastern  
Saturday 9 am - 3pm eastern

[WWW.THEPROTECTIONCENTRE.CA](http://WWW.THEPROTECTIONCENTRE.CA)